

DCM 24 HOUR AIRCRAFT GENERATION CHECKLISTPRE TAKE-OFFH-HOUR 7 JUN 1960XERO[®]
COPY
CO*ITEMS TO BE CALLED TO C.P.

Rev 5/31/67

	1	2	3	4	5	6	*7	8	9	10	*11	12	25X1
	DCM Alert Mtn to start generation	Cmdrs Initial Briefing	Select Acft & Assign Package	Mtn to Secure Nitrogen Oxygen	POL to Secure fuel trucks	DCM Mtng with Contract Pers	Start Mission Acft Preflt	Receive Ruel Load fm Flt Plan	Fers Eqp P/U LOX fm POL	63 to EWS & SIP	TEB,LOX & Refuel #1 & #2	ARC-50 Codes to DCM	
H-HOUR	H-24 H-23:30	H-23:30 H-22:30	H-23:30 H-22:30	H-23:00	H-23:00	H-22:30	H-22:30	H-22:30	H-22:00	H-22:00 H-19:00	H-22:00	H-22:00	
LOCAL TIME	1100 1130	1130 1230	1130 1230	1200 1300	1300 1230	1230 1230	1230 1230	1300 1300	1300 1300	1300 1600	1300 1600	1300 1200	XERO [®] COPY CO
#1 ACTUAL TIME 127							1200				1200	1510	
#2 ACTUAL TIME 131							1200				1200	1530	

	13	14	15	*16	*17	18	19	*20	*21	22	23	24	25X1
	COMMO & IFF Preflt	Install Instr	Select Recovery Crew & give to DCM	INS Preflt	EWS Preflt	Pkg Data avail fm Flt Plan	INS Data avail fm Flt Plan	Pkg Loaded in Acft #1 & #2	SIP Install checked out & Beacon Check	Pkg Data Loaded	INS Data Prepared for Loading	POL Send	
H-HOUR	H-22:00 H-18:00	H-20:00 H-18:00	H-20:00 H-16:00	H-18:00 H-16:00	H-16:00 H-13:00	H-13:45	H-12:45 H-12:00	H-13:00 H-8:30	H-11:00 H-8:30	H-11:00 H-8:30	H-11:00 H-6:00	H-10:45	
LOCAL TIME	1300 1700	1500 1700	1500 1900	1700 1900	1900 2200	2115 2115	2215 2200	2200 0230	2400 0230	2400 0230	2400 0500	0015	XERO [®] COPY CO
#1 ACTUAL TIME 127				1800 1950	1645 1725								
#2 ACTUAL TIME 131				0900 1100	1630 1650								

XERO[®]
COPY
CO

DCM 24 HOUR AIRCRAFT GENERATION CHECKLIST

PRE TAKE-OFF

H-HOUR 07/1100L

* INDICATES ITEMS TO BE CALLED TO C.P.

Rev 5/31/67

	25	26	27	*28	29	*30	31	32	33	34	35	*36
	Crew Chief Standby Acft	Mtn call Security to Sterlize Cockpit	Nitrogen Top Off	Pers Eqp Loaded	Acft Status Brief CC, INS, EWS, Pkg & DCM	Start INS Warmup	Pkg II Preheat	Pkg I Helium Purge Q-Bay	View- finder loaded with film	INS Data Tape Loading	Engineer Cock Acft	Engine Start, Power Switch & Towout #1
H-HOUR	H-4:00 H-Hour	H-4:00 H-3:30	H-4:00 H-3:30	H-3:30 H-3:00	H-3:30	H-3:30	H-3:30	H-2:00	H-2:00 H-1:30	H-2:00 H-1:30	H-1:30 H-1:00	H-35 H-15
LOCAL TIME	0700 1100	0700 0730	0700 0730	0730 0800	0730 0730	0730 0730	0730 0900	0900 0930	0900 0930	0900 1000	0930 1045	1025
#1 ACTUAL TIME	127											
#2 ACTUAL TIME	131											

37 38

	Taxi & Take Off	Monk Rec & gather Rec Gear										
OUR	H-15 H-Hour	H-Hour H+1:00										
#1 ACTUAL TIME	1045 1100											
#2 ACTUAL TIME	1100 1200											

DCM 24 HOUR AIRCRAFT GENERATION CHECKLISTPOST TAKE-OFFH-HOUR

Rev 5/31/67

XERO[®]
COPY
XERO[®]
COPY

	39	40	41	42	43	44	45	46	47	48	49	50
	Standby Spare Acft & Start Engines	Unload Pkg & INS from Spare Acft	Spare Acft Declas	Remove View-finder Film & Map fm Spare	Land & Cool Mission Acft	Secure Mission Acft & Service Engine Oil	SCDM Tape Removed & Given to SIP	Remove View-finder Film & Maps	Remove Blue Dog Tape	Acft Mtn Debrief	Remove Instr Pkg	Move Acft In Hangar

H-HOUR	H+25	H+30 H+2:30	H+2:30	H+2:30	L+30	L+30 L+1:15	L+30 L+1:15	L+30 L+1:15	L+30 L+1:15	L+45	L+1:00	L+1:15 L+1:30
LOCAL TIME												
A1 ACTUAL TIME 127												
A2 ACTUAL TIME 131												

	51	52	53	54	55	56	57	58	59	60	61	
	Unload Pkg & Prepare "TAKE"	INS Erase Data fm Computer	SCDM Data to Flt Plan for Realm 113	SIP Data to OPS	Declass Mission Acft	Pkg "TAKE" to Security	Pkg Submit <input type="text"/> 117 to DCM	Blue Dog Tape to Security	INS/SCDM Tab Run to Security	INS Send SCDM Tape to Security	INS Submit <input type="text"/> 127 to DCM	

H-HOUR	L+2:30 L+3:30	L+2:00 L+3:00	L+3:30	L+3:30 L+4:15	L+4:00	L+5:00	L+5:00	L+5:00	L+5:00	L+9:00	L+20:00	
LOCAL TIME												
A1 ACTUAL TIME												
A2 ACTUAL TIME												

225X1

XERO[®]
COPY
XERO[®]
COPYXERO[®]
COPY
XERO[®]
COPY